

Which version should I use?

ORSR MOBILE

Mobile features

- Mop up mode
- UT and TL list by tag number
- Tag archive, last tag seen
- Android app plots tag location on Google Map

ORSR NETWORK

Stationary reader features

- Reader network to collect data from one spot

ORSR FULL

All of the above

Read the Oregon RFID Temperature Sensor

How to select the version

Type the FW command and answer V for the version number of the boot loader firmware. If it is 4 or larger, the FULL version can be used.

If you get the message “Off page” when installing the ORSR full version, use either the Network or Mobile version.

```
HZGB> FW
ORSR MCU4
Update (Y) ?V=4
```

```
HZGB> FW1
CTRL MCU1
Update (Y) ?V=5
```

Updating reader to use the FULL version

Older readers that do not have version 4 or higher boot loader firmware can have their readers updated. Contact Oregon RFID tech support support@oregonrfid.com for assistance.